




1




2



3




4



27


5




27

27


6




7




8






9







10



28	12	STFX 3.5x13
27	20	Kopplingsskruv7x50
15	8	Glidknapp 4214
ITEM	QTY	PART NUMBER



17	6	Snäcka 12x10
16	6	Kopplingsskruv 35
14	6	Kopplingsskruv 5x30
ITEM	QTY	PART NUMBER



Skötselinstruktion

För att produkten skall fungera så bra som möjligt är det viktigt att regelbundet se över produktens funktion, eventuella skador och slitage.

Skravar och infästningar kontrolleras och efter dras vid behov.

Denna produkt är endast ämnad för inomhus användning.

Förändringar på produkten eller dess konstruktion får inte göras utan särskilda anvisningar från återförsäljaren.

Spara denna instruktion för framtida referens.

Care instructions

For the product to function as well as possible, it is important to regularly review the operation of the product and any damage or wear.

Screws and fasteners checked and tightened if necessary.

This product is for indoor use only.

Changes to the product or its construction should not be done without specific instructions from the dealer.

Save these instructions for future reference.